


Turning Gestures off

If you have noticed that your Laptop keeps blanking out and going to the log in screen frequently, it could be that the touch pad is to blame. You can fix this two ways. You can do critical updates that will update the driver or you can turn it off. There is a setting that is called “Gestures” and is really neat but only if you are aware of it and actually want to use it. It allows the user to quickly lock their computer by using a two finger swipe down the pad. But if you don’t want this or it gets in the way of your daily routine it could be very frustrating. Here are instructions to turn it off.

1. Go to the Control Panel. One way is to type “control panel” in the search bar.



2. Find the “mouse” in the list so and click on it to open the mouse properties.



3. Click the link at the bottom to change the settings. It is in blue and takes a minute to open.



4. Click on the Gestures tab and turn it off (green button in the middle)
5. Be sure to click the Save tab when done or it will not turn off.

DELL | Pointing Devices



Default **Touchpad** Save Cancel

Gestures On/Off Multi Finger Gestures >

Sensitivity

Buttons

Gestures >



Two Finger Gestures

- Panning / Scrolling ⓘ
- Inertial Scrolling ⓘ
- Reverse Scroll Direction ⓘ

Scroll Speed

— ● +

- Zoom ⓘ
- Rotate ⓘ

v.10.1207.101.103 Display Icon in System Tray